

# PROFESSIONAL DENT PULLER 75MM / 100MM / 125MM

MODEL NO: AK100 / AK101 / AK102

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.







Refer to instructions

Wear eye protection

Wear protective gloves

#### 1. SAFETY

#### 1.1 SAFETY INSTRUCTIONS

- □ WARNING! Ensure Health & Safety, local authority and general workshop practice regulations are adhered to when using this equipment.
- ✓ Maintain the dent puller in good condition.
- Replace damaged parts. Use genuine parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- ✓ Use in a suitable work area. Keep area free from unrelated materials and ensure that there is adequate lighting.
- Before each use, check condition of dent puller. If any component is worn or damaged replace immediately.
- □ WARNING! Always wear approved eye (or face) and hand protection when operating the puller.
- ✓ Maintain correct balance and footing. DO NOT over reach, ensure the floor is not slippery, wear non-slip footwear.
- ✓ Keep fingers clear of suction release trigger during use.
- ✓ Keep children and unauthorised persons away from the working area. Ensure workpiece is secure before operating the dent puller.
- Ensure that the workpiece surface is clean, dry and free from oil or grease.
- **DO NOT** exceed the maximum pull capacity of the dent puller.
- **DO NOT** clean the suction cups with solvents or other harsh chemicals.
- **DO NOT** use the dent puller for any purpose other than that for which it is designed.
- DO NOT use the dent puller if any parts are damaged or missing as this may cause failure and/or personal injury.
- DO NOT use the dent puller when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- When not in use, store in a safe, dry, childproof location.

## 2. INTRODUCTION

Specialist device for pulling dents from panels and bodywork. Contoured aluminium handle and suction release trigger give the technician close control

### 3. SPECIFICATION

Model No:	AK100	AK101	AK102
Size:	Ø75mm	Ø100mm	Ø125mm
Maximum Pull Capacity:.	10kg	15kg	20kg
Nett Weight:	0.34ka	0.39ka	0.47ka

#### 4. OPERATION

- **4.1.** Ensure that the workpiece is clean, dry and free from oil and grease.
- **4.2.** Remove the protective cover from the suction cup.
- **4.3.** Holding the handle, firmly push the dent puller into the centre of the dent.
- **4.4.** Pull the dent puller outwards in a controlled manner until the dent has been extracted.
- **4.5.** Lift the suction release trigger to remove the dent puller from the workpiece.
- **4.6.** Refit the protective cover on the suction cup and store in a safe, dry, childproof location.

### 5. MAINTENANCE

- **5.1.** Check condition of suction cup regularly, if damaged replace using genuine parts only.
- **5.2.** Keep dent puller in a clean, serviceable condition, use a damp cloth to clean.



#### **ENVIRONMENT PROTECTION**

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

**Note**: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **Important**: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.